## Technote For Internal Use



## **Mounting of a miniBOOSTER**

Proper mounting of a miniBOOSTER intensifier offers several benefits, such as less noise, less vibrations and trouble-free functions.

To insure a trouble-free function it is important not to squeeze the miniBOOSTER too hard and to mount it on the end-piece sections.

Internal precision parts are located in the middle section of the miniBOOSTER.






**DO NOT** mount on the middle part

Vibration and noise that occur from normal operation of the intensifier can be controlled by using plastic holders such as pipe clamps. Their reducing features are appreciated as being an important contribution to environmental protection and occupational health and safety.







- Tel.: +45 7442 9292
- Fax: +45 7442 4204
- info@minibooster.com